
Service Program Ver.1.2.0
SC-P9080/P8080/P7080/P6080 Service Program
NVRAM BACKUP
Read NVRAM data
ADJUSTMENTS(Individual)
Choose [ADJUSTMENTS (Individual)] to perform specific adjustments.
ADJUSTMENTS(Sequence)
After exchanging a part, choose [ADJUSTMENTS (Sequence)] to access a list of parts and perform their related adjustments.
FIRMWARE UPDATE TOOL
Check and verify the firmwares.
IMAGE PRINT
Print test patterns(PRN) and check Adjustment results
PRINTER SETTING CHANGE & COUNTER RESET
Reset counters & change printer setting.
References
Display Panel Menus and Wiring Diagrams (.pdf)
Exit


1-CR Related Check & Adjustment
2-Print Head Related Parts
3-Ink Supply Parts Check & Adjustment
4-PF Related Check & Adjustment
5- Spectro Proofer
6-Electrical board Related Check & Adjustment
Main board Exchange
Remove Ink Cartridges
Power On (Serviceman Mode)
NVRAM data Backup
Power OFF
Parts Exchange
Power On (Firmware update mode)
Firmware update
Power On (Serviceman Mode)
Check NVRAM clear
NVRAM data Restore
Set Ink Cartridges
Power On
RTC Input
Main board Exchange (Backup NG)
Power supply board Exchange
AID Board Exchange
RTC Input
Set correct Date & Time when Main board is replaced.
1. Check or input "Date" and "Time".
Press [Update] to update Date and Time as the PC time.
2. If date and time need to be set to printer, click [Write].
DATE
2022/ 2/11
TIME
10:14:26
Update
Check
Input
Function Key F11:CR Unlock, F12:CR Lock
Finish